



## 1 : 400



5. Eliminate the detailed padeyes on the box girder, including the bikepath and the counterweights, unless directed otherwise by the Engineer.

SHEET	OF
528B1	

FILE => I:\bb\04-01200\ssgs\contract plans and cco\cco\cco#4\6-update 05-01-09\dgn\akgcc05b.dgn

```

USERNAME => dwi:now
DATE PLOTTED => 01 MAY 2009
TIME PLOTTED => 09:13:02

```